




It's easy to connect your computer to the projector and start presenting. The LP400 ships with CableWizard Lite which has one computer connection. The LP425Z/435Z ships with CableWizard, which has computer, audio, mouse, and monitor connections.



- 1** To connect a computer, plug one end of the CableWizard cable into the video connector on your computer and the other end into the CableWizard connector on the projector.
For sound with your presentation, connect the audio cable. Turn on your laptop and activate its external video by pressing the correct activation commands (sometimes the activation button is labeled with an icon like /).

- 2** Plug the power cord into the projector and into an electrical outlet. Turn on the projector.

- 3** Adjust the focus and image size (use the zoom lens on LP425Z/435Z). Refer to the User's Guide for more information.



SAFETY INSTRUCTIONS: Please read and follow all safety instructions provided in this quick start and your User's Guide **BEFORE** using your new projector. Failure to comply with safety instructions may result in fire, electrical shock, or personal injury and may damage or impair protection provided by equipment. Please save all safety instructions.

Safety Definitions:

- **Warning:** Statements identify conditions or practices that could result in permanent personal injury.
- **Caution:** Statements identify conditions or practices that could result in damage to your equipment.

Safety Symbols:



Attention: For information about usage of a feature, please refer to the User's Guide.



Warning: Hot surface. Do not touch.



An arrow pointing to the lamp door of the projector.

Safety Terms:

- **Warning:** Don't look directly into the lens when the projector is turned on.
- **Warning:** Don't block ventilation openings.
 - **Warning:** To replace the lamp, turn the power off and unplug the power cord. To avoid burns, wait 30 minutes before opening the lamp door. Follow all instructions provided in the User's Guide.
 - **Warning:** Please use the power cord provided. Connect the power cord to a receptacle with a protective safety (earth) ground terminal.



- **Warning:** Refer all service to qualified service personnel. Servicing your own projector will void the warranty.
- **Caution:** Don't set liquids on the projector. Spilled liquids may damage your projector.
- **Caution:** Don't place the projector on a hot surface or in direct sunlight.
- **Caution:** Do not drop the projector. Transport the projector in an In Focus-approved case; see the User's Guide for a list of cases.
- **Caution:** For ceiling mount installations, use the mount recommended in the User's Guide and follow all instructions provided with it.

Customer Service

If you need assistance, call In Focus Customer Service directly at **1-800-799-9911**. Support is free between 5 a.m. and 5 p.m. PST, Monday through Friday. Support is available in North America after hours and weekends for a fee at **1-888-592-6800**. Or, send us an e-mail at techsupport@infocus.com

In Europe, call In Focus in The Netherlands at **(31) 35-6474010**. In Singapore, call **(65) 332-0659**.

InFocus®